



GRIT TAPE REPLACEMENT

Instructions

Johnsonite®
A Tarkett Company

Stair Treads and Nosings

REMOVAL AND INSTALLATION

- 1.** Remove grit tape from stair tread channel by peeling or scraping.
- 2.** Remove excess adhesive using a wire brush. Use a clean white cloth dampened with mineral spirits or denatured alcohol to remove adhesive residue.
- 3.** Install new grit tape by peeling the protective paper liner on the back of the pre-cut replacement grit tape about 2 to 3 inches on one end. Insert the exposed end of the grit tape into the stair tread channel, starting from the edge of the stair tread channel. Continue peeling the protective liner from the back of the grit tape, 2 or 3 inches at a time, until the grit tape is fully installed in the channel.
- 4.** Cut the grit tape 1/16" shorter from each side of stair tread channel to allow for expansion and contraction.
- 5.** Using a 2" steel hand roller, thoroughly roll the new grit tape to ensure proper bonding in the stair tread channel.

Visit www.johnsonite.com for most current installation and maintenance instructions.
Contact Johnsonite Technical Services at (800)-899-8916 ext. 9297 with any questions.



Technical Services Department
16910 Munn Road, Chagrin Falls, Ohio 44023
(800) 899-8916 ext 9297 Fax (440) 632-5643

www.johnsonite.com
email: info@johnsonite.com
© 2014 Johnsonite Inc.