



**Wrapping Johnsonite Millwork
Bull Nose Corner**

NOTE: Results may vary depending on specific profile selected



- Determine the radius of the bullnose corner
- Select a piece of pvc pipe with the same radius as the bullnose corner
- Utilizing a heat gun, warm the back of the piece of Millwork in the area where the bend will occur
- Warm the piece of Millwork until it begins to soften and the face of the piece becomes warm to the touch
- Wrap the heated Millwork tightly around the pvc pipe
- Insert the Millwork tightly wrapped around the pvc pipe into a bucket of clean, cold water
- After a few seconds, remove the pvc pipe and allow the Millwork to continue to cool
- After 15-20 seconds, remove the Millwork from the water and dry the piece with a clean white cloth
- The Millwork will now conform tightly to the Bullnose corner



*This is a reference guide to aid a qualified, professional flooring mechanic in the Millwork Bull Nose corner process. This does not replace our installation instructions. Please visit Tarkett.com for detailed installation instructions or contact your local Tarkett distributor to schedule a training seminar.