

### Resilient Shoe Moulding

#### 1. PROPRIETARY PRODUCT/MANUFACTURER

##### 1.1 Proprietary Product: Resilient Shoe Moulding

##### 1.2 Manufacturer:

Johnsonite, Inc.,  
16910 Munn Road  
Chagrin Falls, Ohio 44023  
Phone: (800) 899-8916  
(440) 543-8916  
Fax: (440) 543-8920  
Tech: Ext 297  
Samples: Ext 299  
Web: [www.johnsonite.com](http://www.johnsonite.com)  
E-mail: [info@johnsonite.com](mailto:info@johnsonite.com)

##### 1.3 Proprietary Product Description:

1.3.1 Construction: Johnsonite Resilient Shoe Mouldings are manufactured from a proprietary thermoplastic rubber compound, high quality additives, and colorants. The formulation exceeds ASTM E 84 (Steiner Tunnel Test) Class C Flammability requirements.

Johnsonite Resilient Shoe Mouldings are designed for interior applications only.

##### 1.3.2 Styles:

**SHU-XX-A:** 1/4" (6.4 mm) wide by 1-1/2" (3.8 cm) high radius profile, 8 ft. (2.4 m) lengths with pressure sensitive adhesive backing, 10 lengths [80 ft. (24.4 m) - 21 lbs. (9.5 kg)] per carton

#### 2. PRODUCT PERFORMANCE AND TECHNICAL DATA

- 2.1 **Hardness** - ASTM D 2240 - Not less than 85 Shore A
- 2.2 **Abrasion Resistance** - ASTM D 3389 - 0.22 mg/cycle
- 2.3 **Fire Resistance:** ASTM E 84/NFPA 255 (Steiner Tunnel Test) - Class A

#### 3. INSTALLATION

3.1 The installation of Johnsonite Resilient Shoe Mouldings should not begin until the work of all other trades has been completed, especially overhead trades. Areas to receive shoe mouldings shall be clean, fully enclosed, weathertight, and maintained at a uniform temperature of at least 65°F for 24 hours before, during, and after the installation is completed. The shoe mouldings shall be conditioned in the same manner. The installation surface shall be smooth, flat to within 1/8" in 10 ft., permanently dry, clean and free of all foreign material, such as dust, paint, grease, oils, solvents, sealers, wallpaper, wallpaper paste, and old adhesive residue. Do not install on exterior surfaces subject to weather. Shoe Mouldings shall be securely adhered to the substrate or Millwork Wall Base profile and installed per the manufacturer's recommended instructions.

**Installation Manual:** Refer to Johnsonite Millwork Installation Instructions for complete installation details.

#### 4. AVAILABILITY AND COST

4.1 Available through authorized Johnsonite distributors nationwide.

#### 5. WARRANTY

5.1 Limited 1 year warranty. For complete details, contact Johnsonite or an authorized Johnsonite distributor.

#### 6. MAINTENANCE

6.1 Refer to Johnsonite Millwork Installation Instructions for complete maintenance details.

#### 7. TECHNICAL SERVICES

7.1 Samples: Submittal samples for verification and approval available upon request from Johnsonite, Customer Service. Samples shall be submitted in compliance with the requirements of the Contract Documents. Accepted and approved samples shall constitute the standard materials which represent materials installed on the project.

7.2 For current Installation and Maintenance Instructions, Architect Specifications, Product Specifications, and other technical data, contact Johnsonite Customer Service at 1-800-899-8916.